

Import Single Pattern to a Pipo tablet

1. Plug the micro usb adapter into the host port
2. Go to the explorer
3. Go to the USB storage
 - a. You should see your patterns now
4. Click and hold the pattern you want
5. Click copy
6. Then go to the home icon in the upper left
7. Click on Nand Flash
8. Click on download
9. Click on the editor that is across the top
10. Click paste
11. Now get out of the explorer
12. Go to perfect stitch
13. Set a quilt area
14. Click on patterns
15. Go to the import/export tab
16. Click on import file
17. Click sd card
18. Click open
19. Click downloads
20. Click open
21. Click on your pattern
22. Click open
23. Click the green check mark when it is finished importing
24. Go back to the patterns tab
25. Pattern will be under imported on the tags

Import Multiple Patterns to a Pipo tablet

1. On your USB put all patterns you want to import into a folder
2. Plug the micro usb adapter into the host port
3. Go to the explorer
4. Go to the USB storage
 - a. You should see your patterns now
5. Click and hold the folder you want
6. Click copy
7. Then go to the home icon in the upper left
8. Click on Nand Flash
9. Click on download
10. Click on the editor that is across the top
11. Click paste
12. Now get out of the explorer
13. Go to perfect stitch
14. Set a quilt area
15. Click on patterns
16. Go to the import/export tab
17. Click on import folder
18. Click sd card
19. Click open
20. Click open
21. The patterns will begin importing at this point
22. Click the green check mark when it is finished importing
23. Go back to the pattern tab
24. Pattern will be under imported on the tags